

ASSEMBLY INSTRUCTIONS

STEP 3
Adjust accordingly for
screen stability.



STEP 2
Align stabilizer with hole.
Place screw through and tighten nut.

STEP 1
Put foot studs through frame
and tighten screws down.



Smithsonian
Institution

ASSEMBLY INSTRUCTIONS

STEP 3
Adjust accordingly for
screen stability.



STEP 2
Align stabilizer with hole.
Place screw through and tighten nut.

STEP 1
Put foot studs through frame
and tighten screws down.



Smithsonian
Institution