

ASSEMBLY INSTRUCTIONS

Dear Valued Customer:

Thank you for purchasing this quality hearth accessory from Pilgrim Home & Hearth!

Please visit www.pilgrimhearth.com to activate your warranty registration.

*When transporting cart from outside to indoors, be sure to clean off all debris to avoid possible damage to floor surfaces. It is not recommended that the cart be rolled across hardwood floors.

STEP 1

Align long upright with foot making sure that axle spacer is pointed to the outside and loosely insert shorter bolt into 2nd hole from axle holder in foot. (Fig 1)

STEP 2

Align shorter upright with foot and loosely insert shorter screw through 3rd hole of foot.

STEP 3

Repeat steps 1 & 2 for opposite side.

STEP 4

Align and loosely attach from the top the cross brace to bottom side of foot and frame using longer screw. Insert into 1st hole. Align and loosely insert screw into other cross brace using 4th hole, same side. (Fig 2)

STEP 5

Insert handle into top loop of long upright. Repeat for opposite side. (Fig 2)

STEP 6

Align and attach from the top the cross braces to bottom of completed side frame following step 4.

STEP 7

Tighten all screws.

STEP 8

Stand frame on short bars. Insert cotter pin through hole on one side of the axle rod. Slide washer on axle rod then wheel making sure to keep inflation nozzle on the wheel facing out. Slide axle rod through bushings on both feet. Slide wheel over axle rod end, making sure to keep inflation nozzle on the wheel facing out. Slide on washer and insert cotter pin.

Courtesy note:

Due to the wide variety of wood floor surface densities and vast performance characteristics, we recommend you use caution to protect your floors if you choose to use a wood cart across a wood flooring surface inside your home.

Large Wheel Wood Cart

Item# 18557

10/2017

